# SR1V

## Cable Actuated Sensor
## Industrial • User Scalable VDC Output

**User Adjustable Stroke Range to 175 inches (3 meters)**

**User Selectable 0–5, 0–10, –5–+5, –10–+10 VDC Output**

**Designed for Outdoor & IP67 environments**

**In Stock for Quick Delivery!**

*175-inch model shown*

6″ [152 mm]  4″ [100 mm]  4,75″ [120 mm]

The SR1V is part of a series of rugged, low-cost, high performance string pots built for wet environments and outdoor applications.  Designed for the rigors of outdoor construction equipment or the demands of a factory floor, the SR1M is the perfect low-cost solution for OEM and stocking distributors.

What sets this sensor apart from other string pots, is the internal programmable digital circuitry that gives the customer a one-size-fits-all approach for many applications.  The SR1V ships factory calibrated to the full stroke range but the output signal can be easily re-scaled to match any stroke down to 1 inch (25 mm).

## Output Signal

0...10 Vdc*

(0% fs.)  (100% fs.)

*Additional Output Options: 0...5, ⁻5...⁺5, ⁻10...⁺10 Vdc*

## Specifications

| | |
|---|---|
| **Full Stroke Range, SR1V-125** | 125 inches (3175 mm), maximum |
| **Full Stroke Range, SR1V-175** | 175 inches (4445 mm), maximum |
| **Minimum Full Stroke Range** | 1 inches (25 mm) |
| **Output Signal Settings** | 0–5, 0–10, –5–+5, –10–+10 VDC |
| **Input Voltage** | 15-30 VDC (10-30 VDC for 0–5, –5–+5 volt signal) |
| **Input Current** | 50 mA, max. |
| **Maximum Output Load** | 20 mA |
| **Accuracy, full stroke range ≥ 10 inches (254 mm)** | .5% FS. |
| **Accuracy, full stroke range < 10 inches (254 mm)** | consult factory |
| **Repeatability** | .1% FS. |
| **Resolution** | .0015% FS. |
| **Output Signal Update Rate** | 1 msec |
| **Maximum Velocity** | 80 inches (2 meters) per second |
| **Maximum Acceleration** | 10 g (retraction) |
| **Measuring Cable Tension** | 23 oz. (6,4 N) ±30% |
| **Sensor** | plastic-hybrid precision potentiometer |
| **Cycle Life** | 250,000 (potentiometer) |
| **Enclosure** | Polycarbonate |
| **Measuring Cable** | .034-inch dia. nylon-coated stainless |
| **Electrical Connection** | M12 Connector (mating plug included) |
| **Environmental Suitability** | NEMA 6, IP67 |
| **Operating Temperature** | -40˚ to 185˚ F (-40˚ to 85˚ C) |
| **Weight** | 2.5 lbs. (1.3 Kg) |

## Electrical Connection

| output signal | connector pin | colorcode (cordset) |
|---|---|---|
| 15...30 vdc | 1 | brown |
| output signal | 2 | white |
| common | 3 | blue |
| n/c | 4 | black |



1.7" [45 mm]  22 AWG (.34mm$^2$)

contact view

13.6 ft. [4 M]

contact view

.25 in [6 mm] max. cable dia.

2.4" [60mm]

## Factory Calibrated Stroke Range

The full scale output signal is set at the factory to the maximum full stroke range.  The ZERO point (output = 0 Vdc) is set at the beginning* of the stroke range (0 inches) and the SPAN point (output = 10 Vdc) is set to the end of the range (125 inches or 175 inches depending on model).

*Important* — The ZERO point is set at the factory with the measuring cable pulled out .125 inches from full retraction.

*This is for the factory setting only and the ZERO may be reprogrammed at full retraction at any time.*



.125-in (3,2 mm)

10 VDC

0 VDC

Full Stroke Range

Factory Set ZERO

Factory Set SPAN

## Cable Exit Direction Options

see fig. 1

see fig. 3

see fig. 2

see fig. 4



## Changing the Cable Exit

### Changing Measuring Cable Exit

To change the direction of the measuring cable, remove the 4 mounting bracket screws and rotate bracket to one of four available positions.  See figures 1 - 4 on the following pages for mounting dimensions.

### Changing Electrical Connector Direction

To change the position of the electrical connector, remove the 4 rear cover screws and carefully separate rear cover from the sensor body.

Rotate the rear cover to desired position being careful to not tangle the wiring harness that runs to the connector.



Measuring Cable

Rear Cover

Mounting Bracket

Electrical Connector

## Internal Controller Board



## Changing Output Signal

### Reprogramming ZERO and SPAN:

Reprogramming ZERO and SPAN:

Though ZERO and SPAN points have been preset at the factory, they can easily be changed to match any desired stroke within the full stroke limits of the sensor.  To reprogram the SR1V to your own settings, remove the rear cover to gain access to the internal controller board.  Locate the push-button on the circuit board and follow the instructions below.

Please note that ZERO and SPAN points can be set independently.  You can set one without setting the other.  This operation must be performed with the sensor under power.  *Important: when you are finished, disconnect power for a couple of seconds to permanently set your new settings.*

### Setting Span:

Set the cable to the desired SPAN limit then depress and hold the button until the STATUS LED begins to flash RED.  Release the button (when the LED is flashing RED, not GREEN) and the flashing will slow down to about two-second intervals which indicates the SPAN value is being set into memory.  When completed, the STATUS LED will display solid GREEN.



### Setting Zero:

Set the cable to the desired ZERO limit and then depress and hold the button until the STATUS LED begins to flash GREEN.  Release the button (when the LED is flashing GREEN, not RED) and the flashing will slow down to about two-second intervals which indicates the ZERO value is being set into memory.  When completed, the STATUS LED will display solid GREEN.  Remove power for 2 seconds then reconnect.



| zero | | span | SW1 | SW2 | SW3 | SW4 |
|---|---|---|---|---|---|---|
| 0 | ... | 5 | off | off | off | off |
| 5 | ... | 0 | on | off | off | off |
| 0 | ... | 10 | off | off | off | on |
| 10 | ... | 0 | on | off | off | on |
| -5 | ... | +5 | off | off | on | off |
| +5 | ... | -5 | on | off | on | off |
| -10 | ... | +10 | off | on | off | off |
| +10 | ... | -10 | on | on | off | off |

*output signal options (VDC)*

The SR1V leaves the factory set with a 0...10 VDC full scale output signal.  The signal can be reversed or changed to either 0...5, -5...+5 or -10...+10 VDC (see illustration) by simply changing a dipswitch located on the controller board.

If you wish to simply reverse the output signal or change it to a different voltage range, you may do so without resetting the "zero" and "span" points.

Remove the rear cover to gain access to the board.

## Fig. 1 - Outline Drawing (as shipped)



| Model | A | B |
|-------|------|------|
| *125-inch* | 2.00 ±.13 [50,8 ±3,3] | 2.37 ±.13 [60,22 ±3,3] |
| *175-inch* | 2.87 ±.13 [72,8 ±3,2] | 3.24 ±.13 [82.2 ±3,2] |

Cable Guide Detail

Eyelet Detail

units are in **inches [mm]** tolerances are ± .04 [1,0] unless otherwise noted

\* tolerance = +.005 –.001 [+.13 –.03]
\*\* tolerance = +.005 –.005 [+.13 –.13]

## Fig. 2 - "Up" Cable Exit Direction



| Model | A |
|-------|------|
| *125-inch* | 3.64 ±.13 [92,5 ±3,3] |
| *175-inch* | 4.54 ±.13 [115,3 ±3,3] |

## Fig. 3 - "Down" Cable Exit Direction



| Model | A |
|-------|---|
| **125-inch** | 2.25 ±.13 [57,2 ±3,3] |
| **175-inch** | 3.17 ±.13 [80,5 ±3,3] |

5.50 [139,7]
.95 [24,1]
.75 [19,0]
.84 [21,3]
Ø.265 [6,73] 4 places
*bottom cable exit location*

4.76 [120,9]
3.61 [91,7]
1.39 [35,3]
A
.58 [14,7]

3.85 [97,8] max.
.65 [16,5]
Ø 4.49 [114,0]
1.18 [30,0]
1.59 [40,4]

## Fig. 4 - "Rear" Cable Exit Direction



| Model | A | B |
|-------|---|---|
| **125-inch** | 2.00 ±.13 [50,8 ±3,3] | 2.37 ±.13 [60,22 ±3,3] |
| **175-inch** | 2.87 ±.13 [72,8 ±3,2] | 3.24 ±.13 [82.2 ±3,2] |

5.50 [139,7]
A
.75 [19,0]
Ø.265 [6,73] 4 places
.84 [21,3]
.65 [16,5]

4.76 [120,9]
B
3.61 [91,7]
2.50 [63,5]
1.39 [35,3]
6.00 [152,4]
4.30 [109,2]

3.85 [97,8] max.
1.59 [40,4]
Ø 4.49 [114,0]
1.18 [30,0]

units are in **inches [mm]**    tolerances are ± .04 [1,0] unless otherwise noted

## Ordering Information

| | | |
|---|---|---|
| Order No. | Order No. | Order No. |
| **SR1V-125** | **SR1V-175** | **9036810-0040** |
| 125-inch stroke range, 0–10 Vdc output, 4-pin M12 mating plug & mounting bracket included. | 175-inch stroke range, 0–10 Vdc output, 4-pin M12 mating plug & mounting bracket included. | for short-run connections, optional 13-ft cordset with 4-pin M12 mating plug. |

13 ft (4 m)
22 AWG (.34mm²)

**NORTH AMERICA**

Measurement Specialties, Inc.,
a TE Connectivity company
20630 Plummer Street
Chatsworth, CA 91311
Tel +1 800 423 5483
Tel +1 818 701 2750
Fax +1 818 701 2799
info@celesco.com

**TE.com/sensorsolutions**

SR1V 12/01/2015